



Where plastic comes to reach its full potential.


Underground Tank

INSTALLATION GUIDE



How to install a HERO ROTO Tank:

- 1) Determine the most suitable location for your Hero Underground tank.
- 2) Ensure you have drawings or sign off from an engineer for your underground tank installation.
- 2) Ensure the manufacturer has stipulated that the tank is manufactured for underground purposes.
- 3) Excavate the hole approximately 10% larger than the dimensions of the tank.
- 4) Using a 1:6 cement: river sand mixture, prepare a bed 100mm – 200mm as the tank base.
- 5) Ensure that the base is free of any sharp objects that may damage the tank. Where extra stability is required use steel reinforcing in the base.
- 6) The base should be compacted for best results.
- 7) Lower the tank into the cavity.
- 8) Add another 50mm of filling mixture and ensuring that the spaces between the feet are filled.
- 9) Fill the tank with water.
- 10) Backfill using 1:6 mixture at 200mm stages, wetting and compacting after every stage.

 (011) 769 2738

 www.heroroto.co.za

Hero Rotomoulders does not accept responsibility for installation and structural costs in case of repair or replacement. All replacements / values are subject to a pro rata to a calculation, based on usage and remaining warranty period.